

POWERFLEX®

PART NUMBER

PFF1-813

DESCRIPTION

ENGINE MOUNT STABILISER BUSH (V6 ONLY)

INSTALLATION GUIDE

Contents (parts per pack):

4 x Polyurethane Bushes 1 x PTFE/Silicone Grease

2 x Stainless Steel Sleeves

2 x Zinc Plated Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the engine stabiliser mount from the vehicle, and press out the rubber bushes including outer shells. Clean away any corrosion from the bores of the stabiliser mount, removing any sharp edges using a rounded file.
2. Fit the Powerflex bushes into both ends of the stabiliser mount as shown in Fig 1.
3. Apply some of the supplied grease to the bore of the bushes and push in the stainless steel sleeves until flush.
4. When fitting the stabiliser back to the vehicle, place the supplied washers on either side of the bush at the engine end of the stabiliser. Washers are not required at the chassis-mounted end.
5. Tension all hardware to the manufacturer's recommended torque settings.

