



PART NUMBER

PFF25-1120

DESCRIPTION

LOWER TORQUE MOUNT INSERT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Bush Insert

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove the torque mount from the vehicle.
2. Clean the large rubber bush of any excess dirt and ensure there are no sharp edges around the top side of the mount.

Note: The original rubber factory insert can remain in place in addition to our new insert.

3. Push the insert into place from the top side of the mount (See photos). Some dish soap may help to lubricate the insert.
4. Refit the torque mount to the vehicle, and ensure to tighten all hardware to manufacturers recommended torque settings.

