

# POWERFLEX®

PART NUMBER

**PFF60-902**

DESCRIPTION

**FRONT ARM REAR BUSH**

## INSTALLATION GUIDE

### Product description:

This polyurethane bush fits into the rear position of the front arm. It is designed to complement PFF60-901 that fits into the front position of the same arm.

### Contents (parts per pack):

- 2 x Polyurethane bushes
- 2 x Aluminium outer shells
- 2 x Stainless steel sleeves
- 1 x Grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original rubber bush from the arm, clean any dirt and corrosion from the bore in the arm.
2. Press the outer shell into the arm from the top side of the arm until the larger diameter of the shell is against the arm..
3. Press the polyurethane bush into the top of the outer shell with the smallest diameter entering the shell first. It may be necessary to apply some washing up liquid to the outside of the bush to ease fitting. In some cases it may be easier to insert the bush into the arm at an angle.
4. Apply some of the supplied grease to the bore of the bush and insert the sleeve into the bush.
5. Refit the arm to the car and tighten all hardware to manufacturers recommended torque settings.

